eGate Gateway-LWDI/LWDIR Quick Start Guide

Introduction

This quick start guide is to describe the product and help you install it. The gateway is preconfigured to Digita LoRaWAN network



Package Contents




NO	Title	Q'TY
1	Browan Pico Next Indoor	1
2	Power adapter	1
3	LoRa Antenna	1
4	LTE Antenna	1

Overview

Note:

- All antenna ports are SMA-type female. Do not connect the antenna to the wrong port.



Installation

- Plug the device to an outlet.
- Wait and see all status leds are lit (Power, Network, LoRa and Service).

Note: Do not push the reset button as it will reset the certificates and render the gateway unusable.

More Information

Scan the QR code on corner to

gateway/detail Notice

- Read the User Guide before starting installation.
- Do not remove the product label.
- The device must not be dismantled or modified in any way.



User Guide



EU Declaration of Conformity

We,

Company name: Browan Communications Inc.

Postal address: No. 15-1 Zhonghua Road, Hsinchu Industrial Park, Hukou, Hsinchu, Taiwan, 30352.

Telephone number: 886 3-600-6899*4870 E-Mail

address:

gordon@browan.com

Declare that the DoC is issued under our sole responsibility and belongs to the following product:

Product:

PicoNext Indoor Gateway

Type

L0006

Batch

Serial number

L0006 is compliance with the essential requirements of CE and FCC.

The object of the declaration described above is conformity with the relevant Union harmonization legislation:

Radio Equipment Directive (RED) 2014/53/EU

The following harmonized standards and technical specifications have been applied:

Title, Date of standard / specification:

EN 55032: 2015 + A1: 2020 + A11: 2020

EN 55035: 2017 + A11: 2020

EN IEC 61000-3-2: 2019

EN 61000-3-3: 2013 + A1: 2019

EN 62311: 2020

EN IEC 62368-1: 2020 + A11: 2020

EN 301 489-52 V1.2.1 (2021-11)

EN 301 489-17 V3.2.4 (2020-09)

EN 301 489-1 V2.2.3 (2019- 11)

Draft EN 301 489-19 V2.2.0 (2020-09)

Contact Us

Website: https://www.browan.com
E-mail: sales@browan.com

Final Draft EN 301-489-3 V2.2.0 (2021-11)

EN 300 328 V2.2.2 (2019-07)

EN 300 220-1 V3.1.1 (2017-02)

EN 300-220-2 V3.2.1 (2018-06)

EN 303 413 V1.2.1 (2021-04)

EN 301 511 V12.5.1 (2017-03)

EN 301 908-1 V13.1.1 (2019-11)

EN 301 908-2 V13.1.1 (2020-06)

EN 301 908-13 V13.1.1 (2019-11)